

Table C-5. Surface elevation and parameters for equations 14 and 15 describing the hydraulics of the Hanford Reach of the Columbia River.

Beginning River Mile	Ending River Mile	Elevation (feet abv MSL)	A <sub>a</sub>	B <sub>a</sub>	A <sub>w</sub>	B <sub>w</sub>
397.1	392.4	450	16.0994	0.6010	99.5337	0.2170
392.4	386.7	450	10.4826	0.6491	46.1598	0.2990
386.7	382.1	450	5.1545	0.6966	10.8665	0.3940
382.1	377.4	450	35.6628	0.5364	798.8506	0.0730
377.4	371.6	450	21.0634	0.6032	292.7820	0.1990
371.6	364.4	450	29.5736	0.5646	374.7002	0.1290
364.4	358.3	450	16.1049	0.6030	91.6599	0.2060
358.3	353.6	450	14.0921	0.6336	82.1749	0.2670
353.6	346.3	450	41.4013	0.5346	940.1158	0.0690
346.3	339.5	450	1.4800	0.8018	1.0554	0.6050
339.5	333.6	450	60.2303	0.5596	664.3698	0.1190
333.6	329.4	450	26.2448	0.6340	129.2020	0.2680
329.4	324.0	450	94.4921	0.5597	1585.1760	0.1190

Table C-6. Surface elevation and parameters for equations 14 and 15 describing the hydraulics of the Clearwater River from Orofino, Idaho to its confluence with the Snake River near Lewiston, Idaho.

Beginning River Mile	Ending River Mile	Elevation (feet abv MSL)	A <sub>a</sub>	B <sub>a</sub>	A <sub>w</sub>	B <sub>w</sub>
42.0	40.6	980.	4.1693	0.693	56.765	0.233
40.6	11.9	900	4.053	0.693	56.234	0.233
11.9	5.0	750	4.241	0.693	57.005	0.233
5.0	0.0	740	5.704	0.693	63.066	0.233